

DYNAMIC CHECKWEIGHERS DWT/HL/H



release date 05-01-2012



CE M12 1383



Automatic checkweighers series DWT/HL/H are dedicated mainly for systems of Control of Packaged Goods. They are designed for load with maximal capacity 7,5 kg. they are applied by food, cosmetics and chemical industry.

Stainless steel construction, control set is based on TMC weighing terminal equipped with alphanumeric keyboard, separate display for mass and 4 line text display for communication between the weighing instrument and operator. Scale is equipped with numerous additional functions, which allows for cooperation with other devices and data base systems.

Scale have EC type approval, and are offered as EC verified

Technical data:

| | DWT/HL 600 H | DWT/HL 1500 H | DWT/HL 3000 H | DWT/HL 6000 H | DWT/HL 7500 H |
|---------------------|--------------------|---------------|---------------|---------------|---------------|
| Max capacity | 600 g | 1500 g | 3000 g | 6000 g | 7500 g |
| Readability | 0,2 g | 0,5 g | 1 g | 2 g | 5 g |
| Tare range | -600 g | -1500 g | -3000 g | -6000 g | -7500 g |
| Working temperature | -10° - +40 °C | | | | |
| Power supply | 230V AC or 120V AC | | | | |
| IP rating | IP 55 | | | | |
| Display | LED and LCD | | | | |

RADWAG

26-600 Radom • Bracka Street 28 • POLAND • Phone: +48 48 3848800 • Fax: +48 48 3850010 • www.radwag.com • e-mail:export@radwag.com